

## Setup instructions for inland Noise Canceling Headphones model number 87077

Step 1. Locate the “Right” earphone. It is labeled as “R” as shown in the photo below.

Step 2. Push on the “R” lightly and go to “Step 3.”



Step 3. After pressing on the “R,” push the battery cover open.



Step 4. Install one AAA battery (not included). After



To reassemble the headphones, please follow the instructions in reverse order.

Step 5. Turning on the noise canceling function.

Located on the Right ear “R”, the ON/OFF switch is located. When the batteries are properly installed and the switch is switched to the “ON” position the “Status LED” will glow red.



Step 6. Adjusting the amount of noise canceling to a comfortable level. Simply scroll the wheel to adjust the level.



Step 7. Adjusting your music volume.

The volume control is located on the audio cable. Simply scroll the wheel to adjust your music to a comfortable listening level. Please note: Under no circumstances is Inland Products, inc. liable if self inflicted injuries resulted from listening to music too loud.

